



Figure 18-3 Garden hose placed briefly in wall cavity to test for obstruction of water flow to weeps.



Figure 18-4 Water should drain immediately and freely from the weep hole immediately below the test location.

